



Crank shaft is turned from 3/4 X 1-1/2 HRS flat bar  
 Turn crank journals first, then main shaft and journals.  
 Put bolts at X while turning main shaft to hold from flexing.  
 Crankshaft Stroke = 1.100  
 Use with a bore of 1.100 to get a 2 cubic inch engine